VERTICAL CD CLOCK RADIO DUAL ALARM

OWNER'S MANUAL



MODEL NO. CR4947

PLEASE READ BEFORE OPERATING THIS EQUIPEMNT

Warnings and Precautions

TO PREVENT FIRE OR SHOCK HAZARDS, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

This symbol, located on back or bottom of the unit, is intended to alert the user to the presence of un-insulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

This symbol, located on back or bottom of the unit, is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Any use of the controls or an adjustment to the procedures other than those specified herein may result in hazardous radiation.

CAUTION : TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.
To reduce the risk of electric shock, do not remove cover (or back). There are no user-serviceable parts inside. Please refer any servicing to qualified service personnel.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designedo provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between he equipment and receiver.
- Connect he equipment into an outlet on a circuit different from that to which the receiver s connected.
- Consult the dealer or an experienced radio/TV technician for help.

Features





Features Defined

1 **POWER** Press the POWER button to turn the unit OFF and ON.

2 **AM / FM** Slide the AM/FM switch to AM or FM band.

3 **TUNING** Rotate TUNING knob to increase/decrease the radio frequency.

4 **CD / RADIO** Slide the CD / RADIO switch to CD or RADIO playing.

5 **VOLUME** Rotate VOLUME knob to increase/decrease the volume sound.

6 **CD DOOR OPEN** Press to open the CD door.

7 **CD DOOR** Using CD DOOR OPEN button to open the CD door.

8 **LCD Display** View the Time, AM/FM indicator, and radio frequency through this Liquid Crystal Display.

9 **PLAY/PAUSE** Press the PLAY/PAUSE button to play or pause CD playing.

10 **STOP** Press the STOP button to stop CD playing.

11 **SKIP/FWD** Press the SKIP/FWD button to skip to the next track on a CD, hold the button to search forward through a track on an a CD. Using the button to set the time when setting the clock / alarm.

12 **SKIP/REV** Press the SKIP/REV button to skip to the previous track on a CD, hold the button to search backward through a track on an a CD. Using the button to set the time when setting the clock / alarm.

13 **REPEAT** Press the button to CD playing repeat mode.

14 **PROG** Press the button to program the CD playing.

15 **RAND** Press the button to CD playing random mode.

16 **ALARM SET 2** Use the ALARM SET 2 button to view and adjust the alarm-2 time, and to set alarm-2 active or deactivate.

17 **ALARM SET 1** Use the ALARM SET 1 button to view and adjust the alarm-2 time and to set alarm-1 active or deactivate.

18 **DISP** Press the display button to switch between clock time or frequency / CD playing time.

19 **SLEEP** Press the SLEEP button to set the sleep timer from 0 ~ 90 minute.

20 **SNOOZE** Press the SNOOZE button to delay the alarm for six minutes after the alarm sounds.

21 **CLK SET** Press the CLK SET button to adjust the clock.

22 **MUSIC/BUZZER** Slide the MUSIC/BUZZER toggle switch to the alarm sound wake to auto (radio / CD) or buzzer mode.

23 **PHONES** Use the PHONE jack to connect head-phone or ear-phone.

24 **AUX IN** Use the AUX-IN jack to connect other audio device to the unit.

25 **FM Antenna** The FM Wire Antenna provides flexibility and range when adjusting the FM reception. An AM Antenna is built into the player.

26 **AC Cord (120V/60 Hz)** The attached AC (Alternating Current) cord provides power to the player.

27 **Battery Back-Up (9V battery)** The Battery Back-Up will save the clock and alarm settings in case of power outage. The display will not be active without AC power (batteries not included).

Installation

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.



Unravel the AC cord and connect it to a conveniently located AC outlet having 120V and 60Hz only. The Clock Display will illuminate and "12:00" will appear in the window.

NOTE: If the AC plug does not fit into a non polarized outlet, do not file or cut the wide blade. If the AC cord is disconnected or if there is a power failure, this electronic clock is designed to continue operating internally (without showing the time on the Clock Display) with a 9 volt battery (not included). To install the battery, remove the battery compartment cover by pressing in on the tab, connect the battery to the terminals of the battery snap inside the compartment (use of an alkaline battery is recommended), then replace battery compartment cover.



Be sure to check the condition of the battery periodically by disconnecting the AC cord and connecting itagain 2 or 3 minutes later. The preset times should continue operating. If the present time does not appear, it indicates the battery is dead or not connected properly. The 9 volt battery will keep the internal times accurately for approximately 30 minutes. If the power is restored after 30 minutes, the times may need to be reset.

BATTERY PRECAUTIONS

Follow these precautions when using a battery in this device:

1. Use only the size and type of batteries specified.
2. Be sure to follow the correct polarity when installing the battery as indicated in the battery compartment. Reversed battery may cause damage to the device.
3. If the device is not to be used for a long period of time, remove the battery to preventdamage or injury from possible battery leakage.
4. Do not try to recharge a battery not intended to be recharged; it can overheat and rupture. (Follow battery manufacturer's directions)

Operations

TO SET OR RESET THE ACTUAL TIME

1. Press the CLK SET button once; the hour will blink.
2. Press the SKIP/FWD button or SKIP/REV to set the present hour .
3. Press the CLK SET button again; the minutes will blink.
4. Press the SKIP/FWD button or SKIP/REV to set the present minute.
5. Press the CLK SET button to confirm the time.

TO SET OR RESET THE ALARM TIME

1. Press the desired ALARM SET button (AL1 or AL2). ; the hour will blink.
2. Press the SKIP/FWD button or SKIP/REV to set the present hour .
3. Press the ALARM SET button again; the minutes will blink.
4. Press the SKIP/FWD button or SKIP/REV to set the present minute.
5. Press the ALARM SET button to confirm the alarm time.

TO SET THE ALARM TO WAKE TO CD

1. Set the alarm time as previously instructed.
2. Slide the RADIO/CD switch to the CD position and slide the ALARM switch to AUTO
3. Insert a CD and make sure the VOLUME is set as desired.
4. After alarm set step ”5” and the CD track will be shown in display.
5. Press the SKIP/FWD or SKIP/REV buttons to select CD track for alarm CD wake up and press ALARM SET button to confirm all setting.
6. When the actual time matches the selected preset alarm time(s), the unit automatically turns on.

Operations

TO SET THE ALARM TO WAKE TO BUZZER

1. Set the alarm time as previously instructed. Slide the MUSIC/BUZZER switch to BUZZER position.
2. After switch to the BUZZER position and make sure the power is off. When the actual time matches the selected preset alarm time(s), the unit automatically turns on.

TO SHUT THE ALARM OFF

1. To shut the alarm off, press the POWER button once and the alarm time will be reset for the next day.
2. Press ALARM SET button (AL1 or AL2) to turn off the alarm and not set it for the next day.

SNOOZE

1. The alarm can be temporarily turned off manually by pressing the SNOOZE button.
2. The alarm will turn back on automatically 6 minutes later. It can be repeated endlessly.

TO ACTIVATE THE SLEEP FUNCTION

1. Press the SLEEP button and "90" will appear on the clock display.
2. "90" will appear and set the unit to turn off after 90 minutes. Press again and it will deduct 10 minutes and so on.
3. Release the SLEEP button the Sleep function will activate and the SLEEP indicator will light solid.
4. Pressing the SLEEP button until normal clock or CD track display appear to turns off the Sleep feature.

Operations

TO LISTEN TO THE RADIO

1. Press the POWER Button to turn the unit on; the POWER indicator will light.
2. Slide the RADIO/CD switch to the RADIO position on the left side of the unit..
3. Tune a station by turning the TUNING control on the right side of the unit. Adjust the VOLUME control on the left side of the unit as desired.

FM: Extend the FM wire antenna for best reception.
AM: Turn the unit for better AM reception.

TO INSERT A CD

1. Open the CD compartment door by pressing on the OPEN/CLOSE area on the up right of the CD compartment door.
2. Gently place a disc, label side up, onto the spindle and gently close the CD compartment door.

TO REMOVE A CD

1. Make sure the CD has stopped and open the CD compartment door by pressing on the OPEN/CLOSE area on the CD compartment door.
2. Hold the edge of the CD and pick it up.

Operations

TO PLAY A CD

1. Insert a CD.
2. Press the POWER button to turn the unit on;
3. The LCD display will light. Slide the RADIO/CD switch to the CD position. (The total number of track will appear in the display).
4. Press the PLAY/PAUSE button to start playback.
5. TO PAUSE PLAYBACK, press the PLAY/PAUSE button again; the display will briefly blink. Press again to resume playback.
6. To skip forward or backward through the tracks on the disc, press the SKIP button. To search forward or backward through the tracks on the disc, press and hold the SKIP button.
7. Adjust the VOLUME control as desired. Press the DISPLAY button when the time is showing to see the number of tracks on the CD.
8. When the disc is through playing, it will stop. Press the STOP button to stop the disc before it is finished.

Note: If a disc is inserted incorrectly, dirty, damaged or not present at all, the display will show, "Err".

TO REPEATEDLY PLAY BACK ONE TRACK

1. Press the REPEAT button once; the RPT indicator will blink.
2. Press the SKIP/FWD or SKIP/REV buttons to select a track and the PLAY/PAUSE button to start playback and the unit will play the same track over and over until the STOP button is pressed.

TO REPEATEDLY PLAY BACK ALL TRACKS

1. Press the REPEAT button twice; the RPT indicator will light solid.
2. Press the PLAY/PAUSE button to start playback and the unit will then play all the tracks on the CD over and over until the STOP button is pressed.

Operations

TO PLAY A CD RANDOMLY

1. Press the RAND button.
2. RDM indicator will light solid.
3. All CD Track will play randomly, press the RAND button again to cancel RANDOM Mode.

TO PROGRAM THE MEMORY (UP TO 20 TRACKS)

1. Press the POWER button to turn the unit on; the POWER indicator will light. Slide the RADIO/CD switch to the CD position.
2. Press the PROG. button once; "01 01" will appear in the display and the PROG. Indicator will blink.
3. Within 7 seconds, select the first track to be played back using the SKIP/FWD or SKIP/REV buttons, then press the PROG. button again. Repeat this step to program additional tracks up to a maximum of 20 tracks.
4. Press the PLAY/PAUSE button to begin playback. The unit will play all the tracks in the order you programmed them, then the PROG. indicator will light solid.

Note: When at the STOP mode, press the PROG. button to enter the Program mode, and then press the STOP button or change the position of the RADIO/CD switch.

Care and Maintenance

Caring for Compact Discs



- Treat the disc carefully. Handle the disc only by its edges. Never allow your fingers to come in contact with the shiny, unprinted side of the disc.
- Do not attach adhesive tape, stickers, etc. tothe disc label.
- Clean the disc periodically with a soft, lint-free, dry cloth. Never use detergents or abrasive cleaners to clean the disc. If necessary, use a CD cleaning kit.If a disc skips or gets stuck on a section of the disc, it is probably dirty or dam-aged (scratched).When cleaning the disc, wipe in straight lines from the center of the disc to theouter edge of the disc. Never wipe in circular motions.



- This unit is designed to play only discs bearing the identification logo as shown here. Other discs may not conform to the CD standard and may not play properly.
- Discs should be stored in their cases after each use to avoid damage.
- Do not expose discs to direct sunlight, high humidity, high temperatures, ordust, etc. Prolonged exposure or extreme temperatures can warp the disc.
- Do not stick or write anything on either side of the disc. Sharp writing instruments or the ink may damage the surface.

Cleaning the Unit

- To prevent fire or shock hazard, disconnect your unit from the AC power source when cleaning.
- The finish on your unit may be cleaned with a dust cloth and cared for as other furniture. Use caution when cleaning and wiping the plastic parts.
- Mild soap and a damp cloth may be used on the front panel.

Troubleshooting Guide

If you experience a problem with this unit, check the chart below:

SYMPTOM	CAUSE	SOLUTION
Unit will not turn on.	AC cord not connected.	Check AC cord connection.
Disc will not play .	CD compartment not closed.	Close CD compartment door.
	Disc inserted incorrectly .	Reinsert disc correctly.
	Dirty or defective CD.	Try another disc.
	Moisture condensation on disc.	Wipe disc with soft cloth.
No sound.	VOLUME control set to minimum.	Increase volume.
	Defective disc.	Try another disc.
Erratic playback.	Dirty or defective disc.	Clean or replace disc.
Time reset to "12:00".	Battery connected improperly nected or dead.	Check the battery.
	Clock not set.	Set the clock.
Alarm does not turn on.	ALARM switch is not in correct position.	Set ALARM switch to the desired alarm.
	Clock is not set.	Set the clock.
	Alarm is not set.	Set the Alarm.
AM or FM, no sound.	Power is not on.	Press the POWER/ALARM RESET button to turn the unit on.
	VOLUME control set to minimum.	Increase volume.

LIMITED PRODUCT WARRANTY

This quality product is warranted to be free from manufacturer's defects in material and workman-ship, provided that the unit is used under the normal operating conditions intended by the manufacturer.

Should you have any problem with this product, please and it is highly recommended to visit our website at www.curtisint.com before you take any other steps as we have additional copies of instruction manuals, operating manuals and trouble shooting tips on our website which gives you the answer on most of the questions you could have in operating the unit.

TERMS OF WARRANTY

C.I. Service Dept. warrants this product to be free from defects in materials and workmanship for 1 year on parts and 90 days on labor.

Nothing within this warranty shall imply that C.I. will be responsible or liable for any damage to any items placed in this product, whether due to any defect of the product, or its use, whether proper or improper.

EXCLUSIONS

Save as herein provided, C.I. Service Dept. (Canada) or C.I. Service Dept. (USA), there are no other warranties, conditions, representations or guarantees, express or implied, made or intended by C.I. or its authorized distributors and all other warranties, conditions, representations or guarantees, including any warranties, conditions, representations or guarantees under any Sale of Goods Act or like legislation or statue is hereby expressly excluded. Save as herein provided, C.I. Service Dept. (Canada) or C.I. Service Dept. (USA), shall not be responsible for any damages to persons or property, including the unit itself, howsoever caused or any consequential damages arising from the malfunction of the unit and by the purchase of the unit, the purchaser does hereby agree to indemnify and save harmless C.I. from any claim for damages to persons or property caused by the unit.

TO OBTAIN REPAIRS UNDER THE TERMS OF THIS WARRANTY

1. The original purchaser must present a copy of the original bill of sale and the service warranty card.
2. Any alterations, abuse, misuse, battery corrosion or accidental damage voids the warranty.
3. The warranty does not cover cabinets and accessories.
4. No warranty or insurance contained or set out shall apply when damage or repair is caused by power failure; damage in transit or when moving the unit; improper power supply; use for commercial or industrial purposes; service calls resulting in customer education, etc.
5. The defective product should be mailed to:

Canada
C.I. Service Dept.
315 Attwell Dr

Toronto, Ontario

M9W 5C1

U.S.A
C.I. Service Dept.
181 Cooper Avenue

Unit 104
Tonawanda, N.Y.

14150

For service assistance and product information, please call: 1-800-968-9853.

If mailing the product, the freight must be prepaid and a money order for $7.00 should be included to cover the cost of insurance and the return of the product.

6. C.I. reserves the right to repair or replace the parts which have become defective.

Model No. _____ Date Purchased _____ Serial No. _____